

BAKERY EQUIPMENT

HL-61010

HAND BOOK

Directions of
Sugar Mill
=====

1. FEATURES:

- a) Stand type.
- b) Coarseness of powder may be adjusted by changing sieve.

2. USAGE:

To mill sugar, fried corn, fried rice, fried bean, mine stone, silicons, etc. to a powder.

3. PROCESS OF OPERATION:

- a) Choose appropriate sieve. There are different meshes of sieve: 60, 70, 80, 90, 100 mesh. 60 holes per inch called 60 mesh.
- b) Release SCREW NUT (or handle), open the COVER PLATE, place a appropriate sieve, then replace and lock the COVER PLATE.
- c) Press the FUNNEL PREVENT PLATE. (To avoid the substance from dropping into motor and affecting the operation).
- d) Put the substance into the FUNNEL.
- e) Place a container under the OUTGATE of powder to accept the milled substance.
- f) Starting the MOTOR.
- g) To pull the FUNNEL PREVENT PLATE, and make the substance go through the FUNNEL and then be grinded, out from the OUTGATE.
- h) To stop up the PREVENT PLATE when all process is finished. Then clean the mill and running idle for 10 seconds. Stop MOTOR.
- i) When finish the work, to release the SCREW NUT (or HANDLE) and open the COVER PLATE to clean the inside and sieve.

4. NOTICE:

Pay attention to the oil quantity in OIL CUP, be sure the oil is enough to smooth the SPINDLE.

5. TO AVOID OBSTACLE:

If the machine can not start, there must be something inside machine. Please release the SCREW and open COVER PLATE to clean inside. Then replace and lock the PLATE.

